

There are two types of the DSI handles, Interior & Exterior.
The name of the types are misleading, the Exterior(Fig. 1) types are threaded like a normal handle, the Interior(Fig. 2) has a bare hole with an allen screw on the side.



Fig. 1



Fig. 2

For a Normal Installation (attached with a machine screw through back - see Fig 3.), a Exterior type should be ordered with DKIT-1/30 or DKIT-2/30 depending on the material the handle is being mounted on.



Fig. 3

Back to Back Installation (Fig. 4) - A Interior type & Exterior type should be ordered with the DKIT-3/30 or DKIT-4/30 depending on the material the handle is being mounted on.



Fig. 4

Wall Mount (Fig. 5) - On concrete wall or wall with no access to backside. On concrete, the wall must be drilled to accommodate the plastic anchor. On wood, no anchor is necessary. Interior type should be ordered with the DKIT-5/30.



Fig. 5

DKIT - All DKIT's excluding the DKIT-5/30 is supplied with a M8 x 130mm machine screw. User must cut (if needed) the screw to accommodate different door thicknesses. The DKIT-5/30 is supplied with a M6 x 65mm self tapping screw and a plastic anchor.

